



US007950212B1

(12) **United States Patent**  
**Figgins et al.**

(10) **Patent No.:** **US 7,950,212 B1**  
(45) **Date of Patent:** **May 31, 2011**

(54) **CUTTERBAR SUPPORT FOR A CROP HARVESTING HEADER**

(75) Inventors: **Ryan M. Figgins**, New Holland, PA (US); **Karl W. Klotzbach**, Ephrata, PA (US); **James F. Rayfield**, New Holland, PA (US); **Sunilkumar C. Machhar**, Lancaster, PA (US); **Gary L. Bich**, New Holland, PA (US); **Douglas D. Sorensen**, Lancaster, PA (US)

(73) Assignee: **CNH America LLC**, New Holland, PA (US)

(\* ) Notice: Subject to any disclaimer, the term of this patent is extended or adjusted under 35 U.S.C. 154(b) by 0 days.

(21) Appl. No.: **12/849,162**

(22) Filed: **Aug. 3, 2010**

**Related U.S. Application Data**

(63) Continuation-in-part of application No. 12/748,550, filed on Mar. 29, 2010.

(51) **Int. Cl.**  
**A01D 67/00** (2006.01)

(52) **U.S. Cl.** ..... **56/181**

(58) **Field of Classification Search** ..... 56/181, 56/153, 15.8, 10.2 E, 504, 17.2  
See application file for complete search history.

(56) **References Cited**

**U.S. PATENT DOCUMENTS**

2,490,311 A 12/1949 Du Rostu  
4,168,075 A 9/1979 Matschinsky

4,177,625 A	12/1979	Knight et al.	
4,313,294 A	2/1982	Martenas	
4,573,308 A	3/1986	Ehrecke et al.	
4,599,852 A *	7/1986	Kerber et al.	56/15.8
4,724,661 A *	2/1988	Blakeslee et al.	56/208
5,157,905 A *	10/1992	Talbot et al.	56/15.9
5,186,216 A	2/1993	Bollier	
5,378,010 A	1/1995	Marino et al.	
5,464,371 A *	11/1995	Honey	460/20
RE35,543 E *	7/1997	Patterson	56/14.4
6,594,983 B1 *	7/2003	Krone et al.	56/341
6,675,568 B2 *	1/2004	Patterson et al.	56/208
7,207,164 B2 *	4/2007	Bomlery	56/10.2 E
7,222,475 B2 *	5/2007	Bomlery et al.	56/10.2 E
7,430,846 B2 *	10/2008	Bomlery et al.	56/10.2 E
2004/0065069 A1 *	4/2004	Dunn et al.	56/10.4
2008/0072560 A1 *	3/2008	Talbot	56/208
2008/0078155 A1 *	4/2008	Coers et al.	56/15.8
2009/0277144 A1 *	11/2009	Honas et al.	56/153
2010/0043372 A1 *	2/2010	Honas et al.	56/181

**FOREIGN PATENT DOCUMENTS**

JP 402117410 A 5/1990

\* cited by examiner

*Primary Examiner* — **Árpád Fábíán-Kovács**

(74) *Attorney, Agent, or Firm* — Michael G. Harms; Patrick M. Sheldrake

(57) **ABSTRACT**

A system for supporting a cutterbar of a crop harvesting header includes a first arm pivotably secured to the header. The first arm includes a first portion configured to support the cutterbar. The first arm includes a second portion including a torsion device having a mass of elastic material connected to an adjustment assembly. The second portion is configured to be pivotably rotatable about an axis by the adjustment assembly to selectably increase or decrease a force applicable to the first portion in order to raise or lower the first portion with respect to the header.

**9 Claims, 12 Drawing Sheets**

