

US008371097B1

# (12) United States Patent McClure et al.

## (10) Patent No.: U (45) Date of Patent:

### US 8,371,097 B1 Feb. 12, 2013

#### (54) BALER GATHERING WHEEL HEIGHT ADJUSTMENT

(75) Inventors: John R. McClure, New Holland, PA

(US); William Dale Hotaling, New Holland, PA (US); Larry D. Hall, Vero

Beach, FL (US); Stephen C.

Schlotterbeck, Okeechobee, FL (US); Singh Chandrashekhar, Lancaster, PA

(US)

(73) Assignee: **CNH America LLC**, New Holland, PA

(US)

(\*) Notice: Subject to any disclaimer, the term of this

patent is extended or adjusted under 35

U.S.C. 154(b) by 0 days.

(21) Appl. No.: 13/244,972

(22) Filed: Sep. 26, 2011

(51) **Int. Cl.** 

 A01D 39/00
 (2006.01)

 A01D 43/02
 (2006.01)

 A01D 75/00
 (2006.01)

(52) U.S. Cl. ...... 56/341; 56/362

See application file for complete search history.

#### (56) References Cited

#### U.S. PATENT DOCUMENTS

2,459,961	Α	*	1/1949	Pollard	 56/372
2,783,606	Α		3/1957	Wilson	
3,125,845	Α		3/1964	Lee	

3,367,094	A *	2/1968	Harwig 56	/364
3,678,669	A	7/1972	Czajkowski	
3,834,142	Α	9/1974	Johnston et al.	
4,182,103	A	1/1980	McNutt	
4,236,372	A *	12/1980	Munro et al 56	/364
4,446,684	A *	5/1984	Frimml et al 56	/341
4,446,685	A	5/1984	Coeffic	
4,803,832	A *	2/1989	Crawford 56	/341
5,400,578	A *	3/1995	Galanti 56	/341
6,449,936	B1*	9/2002	Anstey et al 56	/341
6,543,212	B2 *	4/2003	Tonutti 56	/375
6,594,978	B2 *	7/2003	Viaud 56/10	).2 E
7,165,386	B2	1/2007	Tonutti	
7,617,662	B2	11/2009	Erdmann et al.	
2002/0059790	A1	5/2002	Paulsen	

<sup>\*</sup> cited by examiner

Primary Examiner — Arpad Fabian-Kovacs (74) Attorney, Agent, or Firm — Patrick M. Sheldrake

#### (57) ABSTRACT

A mechanism for connecting outboard gathering wheels to a moveable crop pick-up assembly on a round baler that incorporates a multi-element linkage to enable the rate of vertical movement of the gathering wheels to be different than the rate of vertical movement of the pick-up assembly. As the pick-up assembly is moved vertically by an actuator, the linkage interconnecting the gathering wheels and the pick-up causes the gathering wheels to also move vertically, but at a rate that is different, usually less, than the rate of vertical movement of the pickup. The linkage enables the pick-up to be raised sufficiently for transport without causing the gathering wheels to impinge upon the baler frame as occurs when both are raised at the same rate. Use of tension members in the linkage allows the gathering wheels to up float during operation without damaging the linkage.

#### 14 Claims, 5 Drawing Sheets

