

LIS008676521B2

(12) United States Patent

Vennelakanti et al.

(54) SYSTEM AND METHOD FOR HANDLING WIDE DYNAMIC RANGE SIGNALS ENCOUNTERED IN VIBRATION ANALYSIS USING A LOGARITHMIC AMPLIFIER

(75) Inventors: **V.s.s Kumar Vennelakanti**, Prakasam

(IN); Ramesh Babu Srinivasa, Mysore

(IN)

(73) Assignee: Fluke Corporation, Evertt, WA (US)

(*) Notice: Subject to any disclaimer, the term of this

patent is extended or adjusted under 35

U.S.C. 154(b) by 375 days.

(21) Appl. No.: 12/911,452

(22) Filed: Oct. 25, 2010

(65) Prior Publication Data

US 2011/0098949 A1 Apr. 28, 2011

(30) Foreign Application Priority Data

Oct. 26, 2009 (IN) 2593/CHE/2009

(51) Int. Cl. *G01F 17/00*

(2006.01)

(52) **U.S. Cl.**

(10) Patent No.:

US 8,676,521 B2

(45) Date of Patent:

Mar. 18, 2014

58) Field of Classification Search

(56) References Cited

U.S. PATENT DOCUMENTS

			Elkins 379/101.01
4,528,852	A *	7/1985	Sohoel 73/593
4,884,265	A *	11/1989	Schroeder et al 370/484
6,889,553	B2	5/2005	Robinson et al.

OTHER PUBLICATIONS

Weinstein, Data Transmission by Frequency-Division Multiplexing Using the Discrete Fourier Transform, 1971, IEEE.*

* cited by examiner

Primary Examiner — Stephen Cherry (74) Attorney, Agent, or Firm — Christensen O'Connor Johnson Kindness

(57) ABSTRACT

A data acquisition system for vibration analysis signals includes a logarithmic amplifier for compressing wide dynamic range signals. The logarithmic amplifier replaces attenuators, gain amplifiers, and gain switches used in a conventional system. Further, only a low bit-count analog to digital converter is needed in combination with the logarithmic amplifier. Consequently, the footprint of the system and system cost are reduced.

19 Claims, 2 Drawing Sheets



